







Snaga (W)	A (mm)	L (mm)
400	201,6	472
600	201,6	554
800	302,4	674
1000	302,4	716
1200	604,8	894
1400	604,8	1009
2000	604,8	1374



Automatski reset nakon isključenja zbog pregrevanja



U periodu korišćenja čistite uređaj usisivačem minimalno na svakih mesec dana!



Servis:

**ROVEX** INŽENJERING d.o.o.

Đorđa Stanojevića 11a/ lok15  
11070 Novi Beograd  
Tel: + 381 11 3115208

e-mail: [servis@rovex.co.rs](mailto:servis@rovex.co.rs)

**www.rovex.rs**




**ADAX**   
IP24C, Class II 

Uputstvo za korišćenje


SRB

**ADAX**

①



②



③



## ADAX ECO T, ET

Produženje kabla preko  
produžne kutije.

Elektroinstalaciju sme vršiti  
samo ovlašćeni električar.

Uvoznik i distributer:

**ROVEX** INŽENJERING d.o.o.

Đorđa Stanojevića 11b/ lok7  
11070 Novi Beograd  
Tel: + 381 11 3115208

e-mail: [prodaja@rovex.co.rs](mailto:prodaja@rovex.co.rs)

[www.rovex.rs](http://www.rovex.rs)

